

## INSTRUCTIONS STEPS FOR THE INSTALLATION OF OUR PA034 STANDARD SYSTEM

1. Drill the frame
2. Extrude some sealant in the area between the frame and your structure
3. Install the window by directing the window with the external sliding glass in the driving direction of the vehicle.
4. Fix the window to the structure of the vehicle with screws (not included) Insert the provided rubber profiles for internal and external finishing
5. Seal the holes in the upper part of the window frame

ELE.	CODICE
1	COMPLETE WINDOW
2	SEALANT (NOT SUPPLIED)
3	COVERING SCREW RUBBER PROFILE (PVC002)
4	COVERING WALL OPENING RUBBER PROFILE
5	FIXING SCREWS (NOT SUPPLIED)

