


# Laser Lite 1



1. Unpack the tent and lay out the flysheet and inner. (Note: The inner tent is already attached to the inside of the flysheet)
2. Carefully assemble the alloy poles. Ensure all the joints are fully connected.
3. Insert both short black end poles into the red pockets at each end of the tent under the flysheet vent hood with the flat end in the pocket and secure the pole foot in the eyelet and adjust tension to ensure it is secure.
4. Slide the main pole through flysheet pole sleeve, shown as the line on the diagram above and secure in the eyelets A -B.
5. Peg out the guy lines at each end with the Terra Firma Mini pegs supplied first and then adjust to tension.
6. Peg out the rest of the flysheet (Note: x2 5.6g alloy pegs are used for pegging points A-B, all other peg points use Terra Firma Mini pegs)



Laser Lite 1 is supplied with:  
**x1 alloy main pole.**  
**x2 short alloy end poles**  
**x8 Terra Firma Mini 9g pegs.**  
**x2 5.6g Alloy pegs**

**WARNING: KEEP ALL FLAME AND HEAT SOURCES  
AWAY FROM THIS TENT FABRIC.**

**To validate your warranty, register online at  
[www.terra-nova.co.uk](http://www.terra-nova.co.uk)**

Pour valider votre garantie,  
enregistrez-vous en ligne sur  
[www.terra-nova.co.uk](http://www.terra-nova.co.uk)

Zur Bestätigung Ihrer Garantie registrieren  
Sie sie bitte online unter [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

**For tent pitching and care instructions visit  
[www.terra-nova.co.uk](http://www.terra-nova.co.uk)**

Pour consulter les instructions de  
montage et d'entretien des tentes, visitez  
[www.terra-nova.co.uk](http://www.terra-nova.co.uk)

Anweisungen zur Zeltaufstellung und