



		Spare part number	Spare part number	Colours available	
1	Right upper hinge		692751		
2	Left upper hinge				
3	Left bottom hinge				
4	Right bottom hinge				
5	Thermistor		692776		
6	Thermistor cover				
7	Door switch panel	692801			
8	Technical panel	692802			
9	Circuit board light panel		692803		
10	Control panel				
11	Control housing	692804			
12	Sticker	692805			
13	Fan	692777			
14	Fan cover		691867		
15	Fan net				
16	Light housing		692779		
17	LED light				
18	Light cover				
19	Breakfast tray	692808			
20	Door latch plate		692758		
21	Winter lock support				
22	Plate	692362			
23	Drip cup	692810			
24	Condenser fan cover	691887			
25	Condenser fan	692785			
26	Power cord	691873			
27	2-way valve	692787			
50	Control module	692821			
28	Freezer door	691877			
29	Food retainer	692789			
30	Cover slide out box	691865			
31	Clip shelf large	692791			
32	Shelf	692816			
33	Foaming door		692817		
34	Deco panel	69233227SP			
35	Door Bin	692794			
36	Drawer divider	691878			
37	Vegetable bin slide guide	691874			
38	Door cover	692764			
39	Drawer bin	691860			
40	Upper hinge shaft		691456	27	
41	Silicone blanking cap				
42	Upper hinge shaft				
43	Upper hinge shaft spring				

44	Panel retainer	692768
45	Handle groove	692770
46	Handle	
47	Handle connecting shaft	
48	Big handle spring	
49	Small handle spring	
50	Control module	
	<i>Serial Number range</i>	
	<i>ExxxxDWxxxxx</i>	691391
	<i>Exxx#xDW0026xxxx - Exxx#xDW0042xxxx</i>	
	<i>Exxx#xDW0043xxxx - Exxx#xDW0065xxxx</i>	692821

Note Identification Label

With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.

