NORDISK LEGACY

SINCE 1901



VANAHEIM 24

as

FAMILY / GROUP TENT

Product book

CONGRATULATIONS!

We wish you lots of fun with your new Nordisk Cotton tent

GLÜCKWUNSCH

TILLYKKE!

FÉLICITATIONS

GRATULACJE

LOVES YOU

おめでとうございます

축하

GEFELICITEERD!

祝賀

BUILD UP INSTRUCTION

1

Spread out the tent and loosely attach a few straps to the ground using the tent pegs. Loosen and sort out all guy ropes before you head to the next steps.

Π

If you have bought the matching Nordisk "Zip in Floor" for your tent, the first step is to spread it out and zip this onto the tent.

VANAHEIM 24



2

Open the entrance and place the three poles and the crossbar inside the tent. Attach the crossbar to the three middle poles. Place them in the center of the roof top and lift up the tent. When erected the bottom of the poles must be placed at the center of the ground. Use guy ropes to create tension for the poles to stand.

3

Place one A-pole in the entrance section. The peak of it needs to be pushed through the eyelet at the roof of entrance. Both pole ends fit in the pockets which are attached to the zip in floor. If no floor is attached use the 8 shape webbings to fix the pole ends. Repeat this step on both sides of the tent. Afterwards close the entrance. Use guy ropes to create tension for the A-poles to stand.



4

Erect the tent by inserting all remaining pegs and tighten the guy ropes. Ensure the door is closed to avoid too much tension on opening.

Π

If you have the matching inner cabins for your Nordisk Cotton tent, you can now attach this inside. Find the coloured connection point which indicates where to connect your inner cabin to the tent. Attach the buckle followed by the remaining connection points.

Fasy pitch



TAKE CARE OF YOUR NORDISK COTTON TENT

Before Trek

NOLDISK

- build up the tent from home and **check if everything is ok**.
- **know the environment** you'll go to (sand, hard soil, snow), and check that pegs etc. matches this
- · check that the poles are ok, and if not; buy a new set before you go
- make sure the tent is clean
- ensure that **zippers runs smoothly** (if not, get some zipper spray)

Trek Camp live



In the Camp

- $\cdot\,$ make sure you pitch on an even and big enough surface
- $\cdot\,$ remove sharp rocks and sticks that could harm the tent floor
- stretch the tent as much as possible for optimal strength and water repellency
- \cdot if wet or very windy, you need to re-adjust the tension of the guy ropes
- if very windy, use extra guy ropes and pegs for stability
- $\cdot\,$ put the packsack somewhere where you can find it again
- avoid fire and smoke near the tent be aware of wind directions!
- keep an eye on **guy rope tension** once in a while
- remove all traces from your camp

Living with your tent

- do not use any sort of coating a clean cotton tent has the best water repellency
- · keep it clean with a soft sponge or brush
- use **no harsh chemical cleaning** or machine washing
- **keep it dry**, and if packed down wet, remember to dry it as soon as possible remember that a wet tent is heavier than a dry one
- store in dry surroundings
- $\cdot\,$ check guy ropes and pegs once in a while, and buy new ones if damaged
- \cdot if you have **damaged poles**, your local Nordisk dealer can supply new ones
- $\cdot\,$ be aware that long exposure of sunlight can degrade the fabric
- \cdot love and nurse your tent. If you protect your tent, it will protect you

You can find more information on nordisk.eu

Tips & Tricks

- 1 Do not coat your cotton tent with anything keep the cotton fabric as it is
- 2 Put rain caps on the poles when it's raining

Scan it!

- **3** Installing the inner cabin can give you an even better climate
- 4 The windows in the sides can open, with or without mosquito net
- 5 Use the mosquito net in the doors to enjoy the view in the evening
- 6 Adjust the center pole to increase or decrease tension on the tent



For 360° View, Windtest, How to pitch & Fact sheet



Download app: From the AppStore:

Nordisktents





LEGACY ORIGINAL SPARE PARTS

Makes your Nordisk Cotton tent last longer...



Guy rope, 5,0 mm, 20 meter Item no.: 119048



Nylon webbing with ladder lock Item no.: 802



Ventilation hook Item no.: 805

NOLDISK



Guy rope, 3,5 mm, 20 meter Item no.: 800



Item no.: 801

Guy rope, 5,0 mm, 20 meter

Mosquito mesh, 10 meter Item no.: 807

Velcro for zipper flaps and door Item no.: 809

Full cover rain cap Item no.: 810





Spare parts available!

Rubber part for center pole

YKK zipper slider with puller Item no.: 814

Webbing loop for A frame



8-hook for inner tent Item no.: 816



Triangular slider Item no.: 119045 Item no.: 815



Alu. hook for inner tent Item no.: 819

Original spa





Adhesive fabric patch

804 Green cotton

Zipper p uller Item no.: 806





Cord stopper Item no.: 808


Item no.: 811-813

LEGACY ORIGINAL SPARE PARTS

Makes your Nordisk Cotton tent last longer...







Inner tent packsack Item no.: M - 842




Compression webbing for poles Item no.:820

NOLDISK

Pole bag

Item no.: 818





830 - Kari Diamond 12m²

L - 843



Zip-in floor bag Item no.: S - 824 M - 825 L - 826

Steel V-peg Extreme hold and grip Item no.: 119039

Skewer Strong galvanized steel Item no.: 119038

Steel T peg Extreme strong T shape Item no.: 119037

Steel nail Extreme grip and superior strength Item no.: 119040

Contact your local Dealer

Spare parts available!



Original spare parts



www.nordisk.eu

Nordisk International

Papirfabrikken 74 DK-8600 Silkeborg Tel. +45 7373 4000 Fax +45 7373 8015 info@nordisk.eu

Denmark, International

Nordisk Germany

Max-Weber-Strasse 16 D-25451 Quickborn Tel. +49 (0) 4106 76770 Fax +49 (0) 4106 767714 info@nordisk.de

Germany, Austria, Switzerland